

Eastern Garage Doors – ZT-07 Remote Programming Guide

Universal Programming Steps

Step Action

1. Put Opener in Programming Mode

Consult your specific opener's manual to enter "learn", "program", or "smart" mode. This could involve pressing-and-holding buttons like P + '+' (Steel-Line SD800), LEARN, or a similar control on Merlin or other brands.

2. Initiate ZT-07 Pairing

Once in programming mode, press the button on your garage motor/control panel per your opener's instructions (e.g., the "+" button or Learn) to prepare for remote registration.

3. Sync the ZT-07 Remote

Within 30 seconds, press the button on your ZT-07 remote twice (press and release quickly for each). Wait for confirmation—usually lights on the opener will flash or change.

4. Save the Settings

Press the confirmation button on your motor (e.g., the P button on Steel-Line or the Learn button on Merlin) to store the code. A successful pairing may be confirmed by a light changing (e.g., LED 3 turning on).

Example: Programming to a Merlin Opener

1. Press the Learn button on the Merlin control panel—its LED should begin flashing (indicating programming mode).
2. Press the chosen button on your ZT-07 remote twice within 30 seconds.
3. The Merlin LED will light or pause flashing—remotes are now learned.
4. Press the Learn button again (if required) or wait for the LED to stop flashing.
5. Test your remote; the door should operate as expected.

Quick Overview

- Enter programming mode – refer to your motor's specific method.
- Initiate pairing – follow your motor's prompt (e.g., "+", Learn).
- Press remote button twice – within time window.
- Confirm/save – via motor's button or light.
- Test – ensure it operates.
- Repeat – for any extra remotes.
- Exit programming – automatically or manually.